

Make the most of your Joe...

Joe is compatible with a wide range of OVER-EAR products including transmitters and different receivers. Mix the products you need to create your perfect system.

Compatible with:



OVER-EAR
WWW.OVER-EAR.COM



Joe
Professional Wireless Headphones

WWW.OVER-EAR.COM

What's in the box

Headphones



CHANGE CHANNELS
Slide channel switch to your desired channel.



SWITCH ON
Slide the switch on to turn headphone on, LED light will illuminate.



START AUDIO
Set up transmitter with music playing (see separate product instructions).



CHARGE UP
Ensure Joe is fully charged (plug in to USB socket, charge for up to 2.5 hours).



Joe setup...

MEET JOE



1. Channel selection

Slide the channel switch to select/ change channels.

Toggle between 1-3

2. Power Switch

Slide the power switch to turn headphone on/off.

3. Power socket

Insert charge cable to recharge.

4. LED Indicator

IN USE

LED illuminates when headphone is on (colour depends on channel selected).

CHARGING

[Power off] - LED illuminates red while charging, LED goes turns green when fully charged.

[Power on] - LED illuminates red. LED turns green when fully charged.

5. Folding hinge

Use to fold headphones when they are not in use.

6. Volume

Use + or - to adjust audio input volume.

HOW TO FOLD

Fold headphone cup in towards the band.



Fold back out when you want to use.

TECHNICAL SPECIFICATION

Model Number	OE500L	
Dimensions:	19cm (21.5cm extended)	
Weight:	220g	
Sound:	Stereo	
Frequency Response	30-20,000Hz	
Channel Separation:	>40dB	
System:	UHF/ RF	
Modulation:	FM	
S/N Ratio:	>75db	
Connections:	5v (NK01)	
Power Source:	420mAh 3.7v Lithium Battery	
Charge Voltage:	5v	
Charge Current:	200mA	
Charge Time:	2.5 hours	
Battery Life:	18 hours	
Noise Reduction:	Yes	
Speaker:	Advanced 40mm	
Impedance:	32 ohm	
Power Saving:	N/A	
Operational Distance:	>300m (optimum)	
Frequencies:	Custom i.e. 433MHz/ 863MHz/ 915MHz etc	
LED Colour Typical Frequency		
	EU	USA
Red	863.7MHz	924.5MHz
Green	864.9MHz	925.6MHz
Blue	863.1MHz	923.8MHz

Please note frequencies and other specifications may be changed without notice.

If in doubt please confirm with supplier.

SAFETY INSTRUCTIONS

- Switch off and disconnect equipment from mains before cleaning.
- Do not repair or replace parts for any products.
- Do not use equipment if damaged by water, heat, physical impact etc.
- Do not use or store equipment in or near water, moist or hot environments.
- Keep away from radiators and heat generating electrical equipment such as screens and amps.
- Use only the supplied power cable and accessories with your product.
- Disconnect from power after charging and especially when not being used for long periods of time. Overcharging headphones can cause damage to the battery.
- Ensure that power connection is plugged in properly - not damaged, working within a comfortable temperature & not exposed to direct sunlight.
- Do not overload wall sockets.
- Failure to comply with safety guidelines can result in electrical shock, fire, damage to equipment and invalidate your warranty.
- If in doubt please contact dealer or manufacturer.

DO

Do use headphones and systems at comfortable and safe listening levels.

Do gently clean equipment between uses and users. Hygienic wipes and ear pad covers are available from your supplier.

Do feel free to expand your system. Mix and match with a variety of OVER-EAR transmitters, headphones and receivers.

Do call, email or visit us for help and advice.

DON'T

Don't use 2 or more transmitters on the same channel - they won't work.

Don't use equipment near other wireless apparatus including radio mics, transmitters etc. Frequencies can interfere and result in distorted or no signal.

Don't attempt to repair or modify equipment yourself. This could seriously harm somebody.

Don't use headphones for extended periods of time.



TROUBLE SHOOTING

NO AUDIO / MUSIC?

Check your music playing device is working, connected correctly, playing music with volume turned up full.

Try a different device and audio cable.

Ensure receivers/ headphones are switched on, connected to correct channel and have volume up.

SIGNAL CUTS OUT, INTERFERENCE OR REDUCED RANGE?

Ensure there is no interference caused by other wireless equipment in the vicinity.

If using 2 or more transmitters simultaneously make sure each is on different channels (frequencies). You cannot use 2 transmitters on the same channel in the same place ever. They will cancel each other out, resulting in little or no signal.

NO POWER?

Check the headphones are fully charged and switched on.



NEED HELP?

Feel free to drop us a line at:
Support@over-ear.com